
## Données & Objet connectés

## Projet de fin de module

- 1. Capteur qui envoie toutes les 30 secondes:
  - \* Température
  - \* Luminosité
  - \* Date(heure)
- 2. Communiquer les données avec RabbitMQ
- 4. Stocker les données dans MongoDB
- 3. Produire une prévision avec FBProphet
- 5. Publier les données sur un site









## → Mise en place des capteurs - Partie: HARDWARE








- 1Ghz, Single-core CPU
- 512MB RAM
- Mini HDMI and USB On-The-Go ports
- Micro USB power
- HAT-compatible 40-pin header





Condensateurs 50v 100uF Photo-résistance Thermo-résistance



## → Mise en place des capteurs

- Partie: SOFTWARE







```
time
     datetime import datetime
GPIO.setmode(GPIO.BOARD)
temp pin = 7
light_pin = 11
def rc time (temp pin):
   GPIO.setup(temp_pin, GPIO.OUT)
   GPIO.output(temp pin, GPIO.LOW)
   GPIO.setup(temp pin, GPIO.IN)
     hile (GPIO.input(temp pin) == GPIO.LOW):
       count += 1
   return count
       credentials = pika.PlainCredentials(username='rbmqUser', password='rbmqPassword')
        connection = pika.BlockingConnection(pika.ConnectionParameters(host='192.168.0.17', credentials=credentials))
        channel = connection.channel()
        channel.queue declare(queue='firstQueue')
       dt_string = now.strftime("%d/%m/%Y %H:%M:%S")
       msg = dt_string+"|"+str(rc_time(temp_pin))+"|"+str(rc_time(light_pin))
       channel.basic_publish(exchange='', routing_key='firstQueue', body=msg)
       print({'date': msg.split('|')[0],'temp': msg.split('|')[1],'lum': msg.split('|')[2]})
       time.sleep(300)
```


#### → Mise en place de RabbitMQ Communiquer **B**Rabbit MQ pika pymongo import MongoClient credentials = pika.PlainCredentials(username='rbmqUser', password='rbmqPassword') channel = connection.channel() channel.queue declare(queue='firstQueue') def callback(ch, method, properties, body): print(" [x] Received %r" % body) client = MongoClient('mongodb://192.168.0.17:27017') db = client['epsi iot'] post\_data = { 'ds': body.decode("utf-8").split('|')[0], 'y': body.decode("utf-8").split('|')[2]} result = db.temp.insert\_one(post\_data) post\_data = {'ds': body.decode("utf-8").split('|')[0],'y': body.decode("utf-8").split('|')[1]} result = db.lum.insert one(post data) channel.basic consume(queue='firstQueue', on message callback=callback, auto ack=True) print(' [\*] Waiting for messages. To exit press CTRL+C') channel.start consuming() C:\WINDOWS\system32\cmd.exe - RabbitMQ Sniffer.py Received b'30/03/2020 12:34:29|525|4557' Received b'30/03/2020 12:34:34|535|4600' Received b'30/03/2020 12:34:40|530|4531' Received b'30/03/2020 12:34:45|524|4538' Received b'30/03/2020 12:34:51|526|4536' Received b'30/03/2020 12:34:56|521|4594' Received b'30/03/2020 12:35:02|528|4567' Script PYTHON RABBITMQ MONGODB 192.168.0.17 192.168.0.17:27017




→ Mise en place de fbProphet











## → Mise en place de fbProphet

# Analyser

### Graphique Température – Prévision sur 5 jours




### Graphique Luminosité – Prévision sur 5 jours






### → Convertir les données en C° ou en Lux







# → Mise en place d'un job Automatisation CRON JOB Cron - task: → Toutes les 59 minutes → Exporte les images sur le site Apache2 Graphiques Script PYTHON 192.168.0.17:80 fbProphet

ct@sanctury:/var/www/html\$ crontab -l Edit this file to introduce tasks to be run by cron. Each task to run has to be defined through a single indicating with different fields when the task will and what command to run for the task To define the time you can provide concrete values for minute (m), hour (h), day of month (dom), month (mon and day of week (dow) or use '\*' in these fields (fo Notice that tasks will be started based on the cron' daemon's notion of time and timezones. Output of the crontab jobs (including errors) is sent email to the user the crontab file belongs to (unless For example, you can run a backup of all your user a at 5 a.m every week with: 0 5 \* \* 1 tar -zcf /var/backups/home.tgz /home/ For more information see the manual pages of crontab m h dom mon dow command \*/59 \* \* \* \* python3 -m pytest /gostyle/sonarqube/testa python3 /home/ct/iot/fbprophet.py

## **ANNEXES**

- https://github.com/cbarange/IOT\_EPSI\_B3
- http://sonar.cbarange.ovh/
- https://www.hackster.io/ahmartareen/iot-temperature-sensorwith-raspberry-pi-2-and-thermistor-7e12db